

Quick Start Card

Please see the full Net Link web browser manual if you would like to connect to an Internet Service Provider other than Concentric Network Corporation. Please see the full Net Link Web Browser Instruction Manual for a detailed version of the connection procedure if you have any questions while reading this Quick Start Card.

Installing the Net Link Modem

1. Make sure your Sega Saturn is off.
2. Plug your Net Link modem into the Sega Saturn™ cartridge slot with the Sega Saturn logo facing towards the front.
3. Connect one end of the enclosed 30 foot phone cord to the "Line" jack on the Net Link modem. Connect the other end to the nearest phone jack.

Establishing your Concentric Network account

1. Insert the Net Link web browser into your Sega Saturn and turn on your system.
2. The web browser will load and automatically take you through the registration process. Have a valid credit card handy.
 - Click on "Yes" when asked if you would like to sign up with Concentric Network. You will receive 30 days of free, unlimited connection time when you register with Concentric.
 - Enter necessary information in the appropriate entry blanks by clicking on the entry field with the A Button on the Sega Saturn controller. This will bring up the on-screen keyboard. Click on the appropriate characters with the A Button to fill in the blank and then click on "Enter" when finished.
 - Highlight the next entry blank and repeat.
 - Click on "Submit" when you are finished. You will then be dialed in to Concentric's toll-free registration number.
 - Your Sega Saturn's internal memory will be automatically updated with all necessary information. We strongly recommend that you write all the information down in the Net Link web browser manual in case you accidentally clear your Sega Saturn's internal memory.
 - Your credit card will automatically be billed on a monthly basis following your 30-day free trial. To cancel an account with Concentric Network, you will need to call their toll-free customer support line at 1-(800)-745-2747

Quick Start Card Cont.

1. In order to connect, either click on a city block or click on the "Connect" icon on toolbar.
2. A green box titled "modem messages" will appear. When your connection has been completed, this box will disappear.
3. Now that you are connected you can start to surf the Internet by simply clicking on interesting city blocks.
4. To perform a search simply click on the Excite logo in the sky.
5. If you know a specific site you want to see, simply click on the text bar just above the toolbar and type in the address.
6. To use E-Mail, click on the E-Mail icon on the toolbar
 - To read incoming mail click on the highlighted subject line
 - Click on the NewMail icon to write / send new E-Mail.
7. To disconnect simply turn your Sega Saturn off.

