

Includes 20 16-BIT SEGA GAMES Video Game Console



INSTRUCTION MANUAL

All rights reserved Made in China. Game Software© SEGA. All rights reserved. SEGA, the SEGA

© 2008 AtGames Holdings, Ltd.

At©ames

logo and GENESIS are either registered trademarks or trademarks of SEGA Corporation. Distributed by AtGames under license from SEGA Corporation The content of this document is subject to change without notice.

Console: 144.5mm x 100.5mm x 45.5mm Dimension Controller: 140 x 76 x 30 mm Power Supply 100~240V AC

SPECIFICATION

S	Special Features	Built-in 20 Sega 16bit Games	
Firecore Game Console Appearance and Key List The image below shows the location of the connectors and buttons			

buttons. Each of its function is outlined below. (The illustrations are for reference only.)

10 9

Turn the TV game console's power ON/OFF. 2 Cartridge Slot

1 Power ON/OFF

Slot for additional cartridges 3 MENU Press this button to display g

games

- ame menu. Second Player Game Controller Game controller connected to this jack controls
- 5 First Player Game Controller Jack Game controller connected to this jack controls games in 1-player games and controls the first player in 2-player games.

the second player in 2-player

and the wireless controllers can be used to play

- 6 Infrared Receiver Will work with FIREBOX wirelesee accesoories (note included) Audio Output
- 8 Video Output Video output.
- NTSC/PAL Switch This switch sets the game console to the proper

Audio output.

cartridges. 10 DC 9V Input Jack The power adaptor's DC 9V output plugs into this jack..


cartridge format to fit with different

1

Game Controllers Appearance and Key List

4

The image below shows the appearance and key list of the game controller.



(The illustrations are for reference only.)

7 Z Key Game key Z. 8 Y Key

6 1P / 2P Toggle

Game key Y.

Game key X.

Game key B.

Game key A

9 X Key

11 B Key

12 A Key

Toggle it to switch between the

first player and second player.

- Directional Pad (D-Pad) 2 Directional Pad for game playing. Press the menu key to return to the
 - menu page. 10 C Key Ultra Red Ray Emitter Game key C Emits ultra red rays to connect to the
 - game console Power Indicator
 - Press any key. The indicator will flicker if there is still power left.
- How do you play the games? Connect the game controllers to the TV game console.
 Connect the TV game console to TV using the enclosed AV cable.
 Press the "ON/OFF" button to "ON" to turn on the TV game console

your TV screen.

5. Press "Up" or "Down" on the D-Pad of the first player game controller to select one of your favorite games, then press the "START" key of the first player game controller to enter the selected game.

6. Press the "START" key of first player game controller to start playing game.

Set your TV set's input source to "video in", and the main menu will show in

2. Wireless keypads have the same key layout as wire keypads except for two differences. (i) There is a menu button on the wireless controller, while there is none on the wire controller (ii) There is a 1P/2P toggle switch on the wireless controller (see illustration).

How do you use the wireless controller to play the games?

1. If one or two wired controllers are plugged into the TV game console, it uses the

If wired controllers are not plugged in, the console scans for wireless controllers,

- Toggle it to switch the controller to 1P/2P controller. 3. To switch between a wire controller and a wireless controller, please turn the game player off first, and then plug/unplug the wire controller. Plugging /unplugging the wire controller during play may damage the devices
- How do you go back to game menu while playing the game? Press the "MENU" button and the screen will go back to the game menu page.
- How do you turn off the game console? Press the "ON/OFF" button to "OFF" to turn off the game console.

1. Follow the steps in section "How do you play the games". 2. Press "Up" or "Down" on the D-Pad of the first player game controller to select a two player game, then press the "START" key of the first player game controller to enter the selected game.

3. Press the "START" key of the first player game controller to start playing game.

How do you play the games in cartridge?

Insert cartridge into the cartridge slot. 3. Turn on the TV game console. 4. Press the "MENU" button.

1. Turn off the power of the TV game console.

How do you play two-player games?

- 5. The TV game console will automatically display the game on the cartridge on the screen 6. Press the "START" key of the first player game controller to start playing game.
- 3)

closer to his father, but winning also provides gifts that Alex can utilize for special powers. These will be necessary as the opponents get harder and harder and the danger increases! If Alex can win the ultimate level, he can save his father and win amazing prizes as well! There is not time to lose!

1. Alex Kidd in the Enchanted Castle



2. Altered Beast

C Key: Jumps up and kick In a time of legend, warriors and supernatural foes, Zeus, God of Thunder, summons you from the dead as his champion in the fight of good versus evil. Athena, daughter of Zeus, has been imprisoned by the evil Neff, God of the Underworld, and it is your charge to free her

from his clutches. To do so, you must battle Neff's henchmen until you reach the ultimate challenge. Zeus has

given you one advantage: the ability to capture spirit balls which you can use to transmute into various beast forms. If

Alex Kidd's father's life is in danger! Fortunately, facing danger is what Alex does best! To save his father, he must win round after exciting round of "Paper, Rock and

Scissors". Winning rounds not only moves Alex that much

Directional Pad (D-Pad): Controls the direction.

Start Key (Start): Starts the game. Selects the tool in tool menu.

A Key: Jumps up and kick.

B Kev: Attacks by fist.



5. Bonanza Bros

6. Crack Down

CRACK DOWN

you succeed, Zeus will be your ally for all time. If you fail, only Neff knows what pain will be your fate! Directional Pad (D-Pad): Controls the direction. Presses the Right Key twice to make hero run. Start Key (Start): Starts the game. Pauses and un-pauses game. A Key: Powerful attacks in wide area which takes a lot of B Key: Attack in medium power. Presses to attack while in running status. **C Key:** Tosses forward.

Presses to jump while in running status.

Mobo and Robo Bonanza are enjoying their favorite television show when the picture crackles and a shadowy

figure asks them to collect certain items that he has placed

return the items successfully, Mobo and Robo will be rewarded. The two of them state that they will get the job done in just three minutes. However, little do they know

that each building is packed with security guards who will

raise the alarm if they are caught red-handed. Fortunately

knock the guards unconscious for a few seconds. A huge reward will be given out if Mobo and Robo are apprehended. Help the infamous Bonanza Bros. infiltrate a

both Mobo and Robo are equipped with bullets that can

number of different locations ranging from banks to mansions to casinos and don't get caught!

When many bombs are discovered throughout a large

laboratory, Ben and Andy are called in to dismantle them before the building explodes all around them! Racing from spot to spot, each bomb must be neutralized with smaller

charges before time runs out. Defenses have been placed to make it more dangerous, but Ben and Andy have an array

of weapons to help them achieve their goals. Better call the

Liberty is a dark, crime ridden metropolis, teaming with criminals who are looking to take advantage of the innocent and the weak. ESWAT places you in the game as a member of the Cyber Police force where it is your job to

protect the citizens and stop the criminals. As you advance

through this action-shooter, you will gain rank which will

open up new weapons and defensive capabilities. If you can arrest the criminal masterminds behind the city's

trouble. Liberty may even promote you to chief of the

Directional Pad (D-Pad): Controls the direction.

Directional Pad (D-Pad): Controls the direction.

Start Key (Start): Starts game. Pauses and un-pauses game.

bomb squad! Time is short!

B Key: Shoots.

Start Key (Start): Starts the game. Pauses and un-pauses game.

A Key: Changes bullets.

Attacks with fist if the bullets are ran out. C Key: Bombs in wide area.

6

A Key: Jump B Key: Shot C Key: Jump

figure of a mysterious stranger appears on screen. This

Things are grim. An evil dragon from another galaxy is rapidly approaching Earth and as a space pilot you realize that it is up to you to stop this threat cold. If you fail, your



3. Arrow Flash

RROW

FLASH

dragon in outer space! Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts the game. Pauses and un-pauses game.

A Key: Transforms into Planet or Robot mode. B Key: Shoost. C Key: Attacks enemies with laser while transforming into Attacks enemies with speeding bump while transforms into robot

home will be burnt to a cinder. Your ship provides two distinct modes, each known as an Arrow Flash. Using blast

weapons and defensive shield capabilities, your challenge is formidable. Hit the thrusters; you have a date with a

Strange and deadly aliens have invaded the earth and it is

numerous environments as you fight your way to the mother-ship to face off with the "mother of all aliens". Each character has unique attacks and special abilities that

up to you to stop them! Your battle will take you through

will add strategic variety to your game play. Additionally, mission objectives provide opportunities for exciting power-ups. It will take all your skills to save the Earth!

4. Alien Storm



7. Columns

Directional Pad (D-Pad): Controls the direction. Presses the Right Key twice to make hero run. Start Key (Start): Starts the game. Pauses and un-pauses game. A Key: Powerful attacks in wide area which takes a lot of energy. B Key: Attacks in medium power. Presses to attack while in sprint status. C Key: Tosses forward.

Directional Pad (D-Pad): Controls the direction.

Addictive and ancient, Columns is the game of a bygone


Presses to jump while in sprint status.

(5)

era, originating with Phoenician merchants. Align puzzle pieces to build columns and bring them down. Easy to play, yet challenging to master, this is a game to keep you amused for hours on end. You will quickly understand why this simple puzzler has stood the test of time. Prepare to lose yourself in this game of the ancients.

Start Key (Start): Starts the game.

Pauses and un-pauses game.



8. Decap Attack

DECADITACK

In an odd and colorful world, anything can happen. Max

planet and must be stopped. Chuck D. Head, a headless mummy, rises up as the best hope of this strange world and he will stop at nothing to defeat Max and free the planet.

D. Cap, an evil boss, has taken control of this unusual

Brightly colored lands, unusual foes and powerful and exotic weapons await you as you guide Chuck in his heroic

battle in this side scrolling spectacular!

7)

Start Key (Start): Starts the game. Pauses and un-pauses game.

A Key: Opens tool items menu.

B Key: Attacks.

Directional Pad (D-Pad): Controls the direction.

C Key: Jumps.
Presses twice while jumping on the air to make hero fly.

11. Fatal Labyrinth Many hours of danger and excitement await you in this dungeon crawling favorite! When the Holy Goblet is stolen and taken to Dragonia, the castle of doom, it appears that

all hope is lost for the world. As Trykaar, you represent the last hope for mankind against Dragonia's evil inhabitants. Your quest is to search Dragonia's randomly generated

levels, battle its minions and retrieve the Holy Goblet.

With success comes the eradication of this threat as you acquire the Holy Goblet and return it to its rightful place. Dragonia's victory spells the end of all that is good and holy. You cannot let Dragonia's minions succeed! Directional Pad (D-Pad): Controls the direction.

famed ESWAT squad! Look out criminals; ESWAT is on Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts the game.

9. ESWAT: City Under Siege



10. Flicky

Pauses and un-pauses game. A Key: Jumps. Flies while in armored mode. B Key: Shoots. C Key: Jumps. Flies while in armored mode.

your way through level after level of cat fighting fun in this

Directional Pad (D-Pad): Controls the direction. **Start Key (Start):** Starts the game. Pauses and un-pauses game. A Key: Jumps B Key: Jumps C Key: Jumps. 8

Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts game. Pauses and un-pauses game.

A Key: Uses magic. B Key: Attacks. C Key: Jumps.

Start Key (Start): Starts the game. Pauses and un-pauses game. A Key: Fastens the game round. B Key: Cancels the selected tool items. C Key: Opens the tool items menu Chooses the tool item.



15. Jewel Master

It is a dark time in the Land of Yuria as the evil Death Adder has invaded, kidnapped the princess and seized the Golden Axe. Devastation alone lays in his wake. Three powerful heroes, each with distinct fighting styles, have emerged in a desperate bid to bring justice to Yuria and free the princess. It will take all of the brawn and magic they can muster just to stand a chance of defeating Death Adder! They vow to save the princess or die trying! The rest is up to you.

9)

The peaceful kingdom of Mythgard seemed blessed for all

time. Then the Demon King, Jardine the Mad, came to power and it seemed that all good was gone forever. Jewel Master, weaver of the Elements, was summoned to possess

conjure spells with which to defeat the legions of Evil. As the Jewel Master, you must seek out the remaining rings, reclaim the Elemental Blade, and strike down Jardine the

magical rings of great power and to use these rings to

Mad. Only by wielding the Elemental Blade can

Directional Pad (D-Pad): Controls the direction.

Start Key (Start): Starts game.

Pauses and un-pauses game.

A Key: Uses magic.

B Key: Attacks. C Key: Jumps.

Directional Pad (D-Pad): Controls the direction. Long presses the Up Key for attack upward. **Start Key (Start):** Starts game. Pauses and un-pauses game A Key: Selects the ring options in the left side. B Key: Selects the ring options in the right side.

Mythgard be restored to its former glory!

16. Streets of Rage This city was once a happy, peaceful place... until one day, a powerful secret criminal organization took over. This

C Key: Negative.

vicious syndicate soon had control of the government and even the police force. The city has become a centre of violence and crime where no-one is safe. Amid this turmoil, a group of determined young police officers has sworn to clean up the city. Among them are Adam Hunter, Axel Stone and Blaze Fielding. They decided to put their lives on the line and take back their city through their special hand-to-hand combat abilities. They are willing to risk anything, even their lives, on the Streets of Rage. Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts game. Pauses and un-pauses game.

A Key: Special Attack B Key: Attack C Key: Jump B+C Key: Special Attack (11)

19. Shadow Dancer



kung-fu skills and the help of your faithful dog, it is up to you to stop the evil Ninja's of Union Lizard once and for all and regain the honor of a slain friend. Once New York is safe, you must fight the mighty Lizard King himself to achieve ultimate victory! Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts game. Pauses and un-pauses game.

A Key: Uses the master skill. B Key: Attacks. Long presses to send dog fighting with competitor. C Key: Jumps.

Union Lizard, a vast crime empire, has taken over New York. As Shadow Dancer, a master of martial arts, you must do battle in the name of justice. Using all of your

The call for the greatest fighters in the world has once again been issued! The World Fighting Tournament is back with greater fighters, more special moves and greater


20. Virtua Fighter II

numbers of spectacular locations in which to do battle. The champions of the first tournament are back with some new faces as well. You must use all of your skills to survive the challenges that await! Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts your engine.

Pauses and un-pauses game A Key: Defense. B Key: Fists. C Key: Kicks. 13)

When the babies wander off, there is only one thing to do: FLICKY lead them back to the safety of their nest. Flicky the mother blue jay has just such a task. It won't be easy to get the baby chicks back though! Hungry cats are on the prowl and many surprising hazards waiting to be found. Puzzle

family favorite!



After a stinging defeat in Golden Axe II, the evil lord Dark Guld has regrouped and has come for revenge! Stealing the powerful Golden Axe, a symbol of peace and prosperity, the Dark Guld wants to see the world revert to chaos. Once again, three warriors including a fierce barbarian, a ferocious Amazon and a fearless dwarf are willing to risk their lives to put a stop to the terror. It's time to start the long journey through enemy-infested territory. Fight onward until you reach the final showdown, a battle with Dark Guld himself!

changing strategy at its finest. Your mission is to save captives and get them to safety, and as the leader of a group of mercenaries, it is up to you to decide which ones to use in each challenge. Every fighter possesses unique abilities that could be the difference life and death. You might even pick up a new fighter along the way, adding to the strategic possibilities and fun! Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts the game.

Pauses and un-pauses game.

10)

rescue Adam from the Syndicate.

more enemies were appearing.

Start Key (Start): Starts game. Pauses and un-pauses game.

A Key: Special Attack

C Key: All Flipper

B Key: Attack C Key: Jump

A Key: Attacks.

B Key: Attacks

C Key: Attacks.

Gain Ground is a game of arcade style action and game

14. Gain Ground

OUDD



17. Streets Of Rage 2 - Rues de colère Just having one peaceful year, the city was returned to its nightmarish state and criminals were once again running rampant. Blaze and Axel found the house of Adam was wrecked and a picture of Adam chained to the wall at the feet of Mr. X. Axel and Blaze team up with Adam's younger brother Eddie 'Skate" Hunter and Axel's friend, professional wrestler Max Thunder to free the city and

This time, their weapons were improved, and each of them

was given special ability to fight with their best. However, the enemies were also improved with enhanced ability, and

Directional Pad (D-Pad): Controls the direction.

B+C Key: Special Attack
D-Pad '←' or '→'+ A Key: Special Attack

18. Sonic Spinball Dr. Eggman (AKA Dr.Robotnik) has taken over Mt. Mobius and turned it into a mechanical base. He is using energy from the magma flowing under the volcano to power his Veg-O-Fortress. He has the power to transform helpless animals into robot slaves. Sonic the Hedgehog and Tails must take down this fortress to free the enslaved animals. The only way to make that happen is to trigger an

eruption in the volcano it's built on. Sonic knows this can be done by removing the Chaos Emeralds that keep the volcano stable. Dr. Eggman, however, is also aware of the fragile relationship that exists between the Emeralds and the mountain, and he's set up an elaborate Pinball Defense System to make sure the precious jewels don't go anywhere. Directional Pad (D-Pad): Controls the direction. Start Key (Start): Starts game. Pauses and un-pauses game. A Key: Left Flipper B Key: Right Flipper