

# SEGA

## SERVICE BULLETIN

SEGA Service Department  
45133 Industrial Drive  
Fremont, Ca. 94538

<http://www.sgwservice.com>  
Phone: 650.632.7580  
Fax: 650.632.7594




This service bulletins affects all Zombie Revenge U/R games

**Problem: Joystick knobs work loose and are unscrewed by players during game play.**

**Solution: Secure the joystick knob to the shaft by using the steps below:**

- 1.) Unscrew and remove the joystick knob from the shaft.
- 2.) Clean all threads.
- 3.) Apply super glue(cyanoacrylate) to the threaded hole in the knob.
- 4.) Re-apply the knob to the shaft and tighten allow 10-15 min for glue to dry.

USE GLUE SPARINGLY! (It is not necessary to apply glue to both portions)



Please note that the joystick pictured above may not be the same as the one used in your game, and is shown for clarification purposes only.

*If you have any questions please contact the SEGA Service Department at the numbers given above.*